



# ISTRUZIONI DI MONTAGGIO INSTALLATION INSTRUCTIONS

CODICE: D.019.L2S\_L6S\_LXB

DUCATI MONSTER 695 2006-

- I  
T  
A  
L  
I  
A  
N  
O**
- CONTENUTO DEL KIT MIVV**
- 2 silenziatori
  - 2 tubi di collegamento
  - 2 fasce staffe (A)
  - 2 guarnizioni sotto staffa (B)
  - 2 molle + gommino
  - 4 rondelle in alluminio (D)
  - 2 viti M8x40 TCEI
  - 2 viti M8x60 TCEI
  - 4 dadi M8
  - 2 distanziali Ø30x35
  - 2 bussole alluminio (C)
  - 2 staffe in alluminio
- 1.0 RIMOZIONE DEI SILENZIATORI ESISTENTI**
- 1.1 Svitare il bullone delle staffe di supporto dei silenziatori sul telaio.
- 1.2 Estrarre i silenziatori esistenti e le bussole originali dalle pedane.
- Attenzione:** per evitare scottature togliere i silenziatori esistenti solo se freddi.
- 2.0 INSTALLAZIONE DEI SILENZIATORI MIVV**
- 2.1 Applicare la protezione in gomma (B) sulla staffa (A) e curvare attorno al silenziatore.
- 2.2 Inserire le bussole del kit MIVV (C) e montare le staffe di alluminio senza stringere le viti.
- 2.3 Inserire i tubi di collegamento.
- 2.4 Inserire i silenziatori MIVV e fissarli alle staffe in alluminio con i distanziali del kit MIVV. Non stringere le viti.
- 2.5 Regolare la posizione e stringere tutte le viti.
- 2.6 Montare le molle.

- MIVV KIT CONTENT**
- 2 silencers
  - 2 link pipes
  - 2 brackets band (A)
  - 2 rubber under bracket (B)
  - 2 springs + rubber
  - 4 aluminum washers (D)
  - 2 socket head screw M8x40
  - 2 socket head screw M8x60
  - 4 nuts M8
  - 2 spacers Ø30x35
  - 2 Aluminium bush (C)
  - 2 Aluminium brackets
- 1.0 REMOVAL OF THE EXISTING SILENCERS**
- 1.1 Unscrew the bolt of the fixing brackets of the silencers on the frame.
- 1.2 Remove the existing silencers and the original bushes from foot rests.
- Warning:** To avoid burns remove the existing silencers only when they are cold.
- 2.0 INSTALLATION OF THE MIVV SILENCERS**
- 2.1 Place the rubber protection on the fixing bracket and to bend around the silencer.
- 2.2 Insert the bushes of the MIVV kit and to mount the aluminium bracket without tighten the screws
- 2.3 Insert the link pipes.
- 2.4 Insert the MIVV silencers and fixing them to the aluminium bracket with spacer of the MIVV kit. Don't tighten the screws.
- 2.5 Fit the right position and tighten all the screws.
- 2.6 Mount the springs.

**E  
N  
G  
L  
I  
S  
H**



